

Rainstore3 Technical Specification

With Geotextile Fabric Liner

SECTION 02630 (Storm Drainage Detention & Exfiltration)

PART 1 - GENERAL

1.01 General Provisions

- A. The Conditions of the Contract and all Sections of Division 1 are hereby made a part of this Section.

1.02 Description of Work

- A. Work Included:
 - 1. Provide excavation and base preparation per Geotechnical Engineer's recommendations and/or as shown on drawings, to provide adequate support for project designs loads and safety from excavation sidewall collapse. See 2.02 Materials.
 - 2. Provide Rainstore3 system products including Rainstore3 units, geotextiles, geogrids, inlet and outlet pipe with connections and installation per the manufacturer's instructions furnished under this section.
- B. Related Work:
 - 1. Subgrade excavation and preparation under Section 02300 - Earthwork.
 - 2. Subsurface drainage materials - Section 02700 - Subsurface Drainage and Structures, as needed.

1.03 Quality Assurance

- A. Follow Section 01340 requirements.
- B. Installation: Performed only by skilled work people with satisfactory record of performance on pipe, chamber, or pond/landfill construction projects of comparable size and quality.

1.04 Submittals

- A. Submit manufacturer's product data and installation instructions.
- B. Submit a 20" x 20" section of Rainstore3 product for review. Reviewed and accepted samples will be returned to the Contractor.
- C. Submit material certificates for geotextile, geogrid, base course and backfill materials.

1.05 Delivery, Storage, and Handling

- A. Protect Rainstore3 cells from damage during delivery and store under tarp to protect from sunlight when time from delivery to installation exceeds one week. Storage should occur on smooth surfaces, free from dirt, mud and debris.
- B. Handling is to be performed with equipment appropriate to the size (height) of cells and site conditions, and may include, hand, handcart, forklifts, extension lifts, small cranes, etc., with care given to minimize damage to spacer bars and surrounding cells.

1.06 Project Conditions

- A. Review installation procedures and coordinate Rainstore3 work with other work affected, such as grading, excavation, utilities, construction access, erosion control to prevent all non-installation related construction traffic over the completed Rainstore3 installation, especially with loads greater than design loads.

- B. Cold weather:
 1. Do not use frozen materials or materials mixed or coated with ice or frost.
 2. Do not build on frozen work or wet, saturated or muddy subgrade.
 3. Care must be taken when handling Rainstore3 cells when air temperature is at 40 degrees or below as plastic becomes brittle.
- C. Protect partially completed Rainstore3 installation against damage from other construction traffic when work is in progress, and following completion of backfill, with highly visible construction tape, fencing, or other means until construction is complete.
- D. Protect adjacent work from damage during Rainstore3 installation.

PART 2 - PRODUCTS

2.01 Availability

- A. Manufacturer: (Rainstore3) Invisible Structures, Inc., 1597 Cole Blvd., Golden, Colorado 80401. Call from USA and Canada 800-233-1510 toll free, (International 303-233-8383), Fax 800-233-1522 (International 303-233-8282).
- B. Distributor:

2.02 Materials

- A. Base of Excavation: Shall be smooth soil, level and free of lumps or debris. Compact to at least 90% or as required by Engineer. Structural fill material may be used to amend the structural capacity of the soil, and should be placed on top of the geogrid layer if needed. Materials that can not be stabilized by compaction, such as sand and/or drainage rock, should be avoided.
- B. Geogrid: Use geogrid product, such as Tensar BX1200, or equal, to overlay the excavation floor, the assembled cells, and above the completed liner, extending at least twice the width of side backfill, with geogrid joints overlapped by at least 12" .
- C. Geotextile: Shall be non-woven PP or PET with a weight of at least 8 oz per square yard, appropriate for the soil type and depth conditions, placed on the floor of the excavation, the sides of the chamber, and chamber top.
- D. Rainstore3 Cells: Injection molded plastic units (layers) 1x1x0.1 m (40"x40"x4") high, 0.1 m³ each) assembled into vertical columnar cell structures of variable height (custom for each project) with each layer consisting of hollow rings rising from a strong open grid Unit weight = 6.4 kg (14.2 lb.), volume = 6% solid.
- E. Side Backfill: Structural fill or sand materials, free from lumps and debris or any other sharp materials to backfill along the sides of the cellular structure, taking care to compact with powered mechanical compactor, in lifts that do not exceed 12", to provide a settlement-free surface over the top and sides of the structure.
- F. Top Backfill: Use 12" minimum to 36" maximum depth of 3/4" minus sandy/gravel roadbase material (with fines less than 3%). If backfill mixture must be custom mixed, use a ratio of 2 parts clean 3/4" drainage rock to 1 part clean sharp sand.
- G. Utility Marker: Use metallic tape at corners of install to mark the area for future utility detection.

PART 3 - EXECUTION

3.01 Inspection

- A. Examine prepared excavation and conditions for smoothness, compaction and level. Do not start Rainstore3 installation until unsatisfactory conditions are corrected.

- Check for presence of high water table, which must be kept at levels below the bottom of the Rainstore3 structure at all times.
- B. Installation constitutes acceptance of existing conditions and responsibility for satisfactory performance. If existing conditions are found unsatisfactory, contact Project Manager for resolution.

3.02 Preparation

- A. Place geogrid over prepared grade, with any joints overlapped by a minimum of 12", extending over the entire excavation bottom. Place fabric for sides a minimum of 20" inside the outer perimeter of the cells prior to placement of the cells. It is helpful to identify the outline of the structure on the floor of the excavation, using spray paint or chalk line, to ensure squareness during cell placement.

3.03 Installation of Rainstore3 Cells

- A. Install Rainstore3 cells by placing side by side, with grid side down. Try to place sides of cells without damaged bumpers along outside of structure to resist backfill forces against fabric and liner materials. Place metallic tape on top corners of install to mark the area for future utility detection. Place a layer of geogrid directly over the top of the cells to bridge columns and joints and provide a secure walking surface. Place geotextile fabric layer over the top and sides to prevent soil entry into the chamber. Take great care to avoid damage to fabric liner material during placement.
- B. After placement of Rainstore3 cells, bring liner material up the sides and over the top of the structure, overlapping or sealing joints per manufacturers recommendations. Fold excess fabric at corners to lay flat against sides of structure, securing folds and seams with staples or similar methods.
- C. Identify locations of inlet, outlet, inspection ports, and any other penetrations of the liner, securing pipe into prefabricated boots with stainless steel pipe clamps. Support pipe in trenches and during backfill operations to prevent damage to liner or pipe.
- D. With chambers greater than 1.2 meters (4 feet) deep, place piles of cover material over closed chamber top surface along the edge of the chamber to provide vertical load on perimeter cells. This will ensure compression of the columns and aid in resistance to side pressures from backfill operations.
- E. Use a powered mechanical compactor to conduct backfill operations on structure sides with care to avoid damage to liner while providing required compaction forces to the top level of the structure.
- F. Place a geogrid layer over the top of the structure, extending beyond the outside edge of the excavation by at least 40". Any joints must be overlapped by a minimum of 12".
- G. Place sufficient sandy gravel backfill material over geogrid to ensure support of design loads. Place cover backfill in 6" lifts and compact with vibrating plates or walk-behind rollers (do not use drivable rolling compactors) to a minimum of 95%, with a minimum depth of 12" and a maximum depth of 36". Take care to place backfill on top of structure and avoid damage to structure or liner, using low pressure tire or track vehicles.
- H. Ensure that all non-chamber construction traffic be kept away from the limits of excavation until the project is complete and final surface materials are in place.
- I. Place surfacing materials, such as groundcovers (no shrubs or trees), or paving materials over the structure with care to avoid displacement of cover fill and damage to surrounding areas.

3.04 Cleaning

- A. Perform cleaning during the installation of work and upon completion of the work. Remove from site all excess materials, debris, and equipment. Repair any damage to adjacent materials and surfaces resulting from installation of this work.

END OF SECTION

If you have any questions regarding this specification, please call
Invisible Structures, Inc. 1-800-233-1510

Version 07/04